



JDS-12

Disc Sander

JR056 1 ~230V 50Hz

PARTS LIST



Импортер в РФ: ООО «ИТА Технолоджи»


105082, Москва, Переведеновский пер., д. 17

www.jettools.ru

Made in PRC / Сделано в КНР

P-JR056 2025-12

Parts Breakdown for JDS-12 Disc Sander



Parts List for JDS-12 Disc Sander

Index No.	Part No.	Description	Size	Qty
1	<u>GB/T 70.2</u>	<u>Pan Head Screw</u>	<u>M5x10</u>	5
2	<u>JDS12-A02</u>	<u>Disc Cover</u>	<u>-</u>	1
3	<u>JDS12-A03</u>	<u>Abrasive Disc</u>	<u>-</u>	1
4	<u>GB/T 70.3</u>	<u>Flat Head Screw</u>	<u>M6x20</u>	1
5	<u>JDS12-A05</u>	<u>Special Washer</u>	<u>-</u>	1
6	<u>JDS12-A06</u>	<u>Aluminum Disc</u>	<u>-</u>	1
7	<u>JDS12-A07</u>	<u>Foot</u>	<u>-</u>	4
8	<u>JDS12-A08</u>	<u>Guide Plate</u>	<u>-</u>	2
9	<u>GB/T 70.1</u>	<u>Socket Head Screw</u>	<u>M6x12</u>	4
10	<u>JDS12-A10</u>	<u>Lock Handle</u>	<u>-</u>	2
11	<u>JDS12-A11</u>	<u>Guide Screw</u>	<u>-</u>	2
12	<u>JDS12-A12A</u>	<u>Miter Gauge Assembly</u>	<u>-</u>	1
12.1	<u>JDS12-A12.1</u>	<u>Knob</u>	<u>-</u>	1
12.2	<u>JDS12-A12.2</u>	<u>Plastic Washer 6mm</u>	<u>-</u>	1
12.3	<u>JDS12-A12.3</u>	<u>Miter Gauge</u>	<u>-</u>	1
12.4	<u>GB/T 818</u>	<u>Pan Head Screw</u>	<u>M4x6</u>	1
12.5	<u>GB/T 95</u>	<u>Flat Washer 4mm</u>	<u>4mm</u>	1
12.6	<u>JDS12-A12.6</u>	<u>Pointer</u>	<u>-</u>	1
12.7	<u>JDS12-A12.7</u>	<u>Sliding Bar</u>	<u>-</u>	1
13	<u>GB/T 819.1</u>	<u>Flat Head Screw</u>	<u>M6X16</u>	4
14	<u>JDS12-A14</u>	<u>Table</u>	<u>-</u>	1
15	<u>JDS12-A15</u>	<u>Left Angle Plate</u>	<u>-</u>	1
16	<u>JDS12-A16</u>	<u>Right Angle Plate</u>	<u>-</u>	1
17	<u>GB/T 96.2</u>	<u>Flat Washer</u>	<u>6mm</u>	4
18	<u>GB/T 41</u>	<u>Hex Nut</u>	<u>M6</u>	4
19	<u>JDS12-A19</u>	<u>Thread Forming Screw</u>	<u>-</u>	3
20	<u>JDS12-A20</u>	<u>Switch</u>	<u>-</u>	1
21	<u>JDS12-A21</u>	<u>Upper Switch House</u>	<u>-</u>	1
22	<u>JDS12-A22</u>	<u>Thread Forming Screw</u>	<u>-</u>	2
23	<u>GB/T 818</u>	<u>Pan Head Screw</u>	<u>M5x8</u>	4
24	<u>GB/T 95</u>	<u>Flat Washer</u>	<u>5mm</u>	1
25	<u>GB/T 818</u>	<u>Pan Head Screw</u>	<u>M5x8</u>	1
26	<u>GB/T 93-</u>	<u>Lock Washer</u>	<u>5mm</u>	1
27	<u>GB/T 862.1</u>	<u>Serrate Washer</u>	<u>5mm</u>	1
28	<u>JDS12-A28</u>	<u>Lower Switch House</u>	<u>-</u>	1
29	<u>JDS12-A29</u>	<u>Strain Relief</u>	<u>-</u>	1
30	<u>JDS12-A30</u>	<u>Power Cord</u>	<u>-</u>	1
31	<u>GB/T 818</u>	<u>Pan Head Screw</u>	<u>M4x8</u>	2
32	<u>GB/T 93</u>	<u>Flat Washer 4mm</u>	<u>4mm</u>	2
33	<u>GB/T 95</u>	<u>Flat Washer 4mm</u>	<u>4mm</u>	2
34	<u>JDS12-A34</u>	<u>Capacity Cover</u>	<u>-</u>	1
35	<u>JDS12-A35</u>	<u>Capacity</u>	<u>-</u>	1
36	<u>GB/T 70.1</u>	<u>Socket Head Screw</u>	<u>M5x25</u>	3
37	<u>GB/T 93</u>	<u>Lock Washer</u>	<u>5mm</u>	3
38	<u>JDS12-A38</u>	<u>Disc House</u>	<u>-</u>	1
39	<u>GB/T 276</u>	<u>Ball Bearing</u>	<u>6204-2RS</u>	1
41	<u>GB/T 1096</u>	<u>Key</u>	<u>5x5x25mm</u>	1
42	<u>JDS12-A42</u>	<u>Rotor</u>	<u>-</u>	1
43	<u>JDS12-A43</u>	<u>Case</u>	<u>-</u>	1
44	<u>GB/T 894</u>	<u>Retaining Ring</u>	<u>17mm</u>	1
45	<u>GB/T 276</u>	<u>Ball Bearing</u>	<u>6203-2RS</u>	1
46	<u>GB/T93</u>	<u>Spring Washer</u>	<u>-</u>	1
47	<u>JDS12-A47</u>	<u>Rear Cover</u>	<u>-</u>	1
48	<u>GB/T 95</u>	<u>Flat Washer</u>	<u>5mm</u>	3
49	<u>GB/T 93</u>	<u>Lock Washer</u>	<u>5mm</u>	3

Parts List for JDS-12 Disc Sander

Index No.	Part No.	Description	Size	Q'ty
50	GB/T 818	Pan head screw M5X8	M5x8	3
51	GB/T 93	Lock washer 5mm	5mm	3
52	GB/T 818	Pan head screw M5x25	M5x25	3
53	JDS12-A53	Fan	—	1
54	JDS12-A54	Fan cover	—	1
	—	—	—	—
	JDS12-WL	JET Warning Label (Not shown)	—	1
	JDS12-ID	JET ID Label (Not shown)	—	1
	JDS12-ML	JET Motor Label (Not shown)	—	1
	JET-LOGO	JET Logo with Adhesive (Not shown)	—	1
	JET Model Logo JDS 12	JET Model Logo with Adhesive	—	1
	—	—	—	—
	—	—	—	—
	—	—	—	—
	—	—	—	—

Wiring Diagram for JDS-12 Disc Sander

	<u>colour of strands</u>	<u>Litzenfarben</u>	<u>couleur des cordons</u>
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	<u>violet</u>	<u>violett</u>	violet

	<u>meaning of symbol</u>	<u>Bedeutung der Zeichen</u>	<u>interprétation</u>
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschuttschalter	déclencheur surcharge
L	<u>machine lamp</u>	<u>Maschinenleuchte</u>	lampe
LS	<u>limit switch</u>	<u>Positionsendschalter</u>	micro

JR056..... ~ 230V, 50Hz

