



JPJ-8HH-M
JPJ-8HH-T

Parallelogram Jointer

JR037....230/50/1

JR038....400/50/3


PARTS LIST



Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д. 17
www.jettools.ru

Made in PRC / Сделано в КНР

Parts Breakdown View for JPJ-8HH-M/JPJ-8HH-T Parallelogram Jointer—A



Parts List for JPJ-8HH-M/JPJ-8HH-T Parallelogram Jointer

Index No.	Part No.	Description	Size	Qty.
1	JPJ8HH-001	Knob M12		1
2	JPJ8HH-002	Screw Shaft, M12x20, M10x15, 80L		1
3	JPJ8HH-003	Brushing		1
4	JPJ8HH-004	Eccentric Shaft		1
5	GB77	Socket Set Screw	M6x16	2
6	GB79	Socket Set Screw	M8 x12	1
7	JPJ8HH-007	Fence Carriage		1
8	GB41	Hex Nut	M6	1
9	GB5781	Hex Cap Screw	M6x25	1
12	JPJ8HH-012	Collar		1
13	JPJ8HH-013	Fence Support		1
14	GB96	Flat Washer	12mm	1
15	GB41	Hex Nut	M12	2
16	GB70.1	Socket Head Cap Screw	M10x30	2
17	GB96	Flat Washer	10mm	2
18	GB70.1	Socket Head Cap Screw	M5x16	3
19	JPJ8HH-019	Fence Gib		1
20	JPJ8HH-020	Eccentric Shaft		1
21	GB96	Flat Washer	8mm	1
22	GB41	Hex Nut	M8	1
23	JPJ8HH-023	Shaft		2
24	GB70.1	Socket Head Cap Screw	M8x30	4
25	GB96	Flat Washer	6mm	1
26	JPJ8HH-026	Pointer		1
27	GB96	Flat Washer	6mm	1
28	GB818	Pan Head Cap Screw	M6x16	1
29	JPJ8HH-029	Adjust Handle		1
30	JPJ8HH-030	Index Pin Assembly		1
31	JPJ8HH-031	Roll Pin	3x20	1
32	JPJ8HH-032	Compression Spring		1
33	GB5781	Hex Cap Screw	M6x25	1
34	GB41	Hex Nut	M6	1
35	JPJ8HH-035	Swivel		1
36	JPJ8HH-036	Lock Collar		1
37	GB5781	Hex Cap Screw	M8 x 12	1
38	JPJ8HH-038	Lock Collar		2
39	GB5781	Hex Cap Screw	M8 x 12	2
40	JPJ8HH-040	Clamp		1
41	JPJ8HH-041	Threaded Clamp		1
42	JPJ8HH-042	Tilt Scale		1
43	GB818	Pan Head Cap Screw	M6x10	1
44	GB96	Flat Washer	6mm	1
45	JPJ8HH-045	Knob		1
46	JPJ8HH-046	Shaft		1
47	JPJ8HH-047	Fence		1
48	JPJ8HH-048	Scale		1
49	JPJ8HH-049	Rivet	2x4mm	2
50	JPJ8HH-050	Infeed Table		1
51	JPJ8HH-051	Table Shaft 202mm		4
52	JPJ8HH-052	Extension Table		1
53	GB70.1	Socket Head Cap Screw	M6x20	2
54	JPJ8HH-054	Chip Deflector		1
55	GB70.1	Socket Head Cap Screw	M6x12	2
56	GB70.1	Socket Head Cap Screw	M8x80	4
57	JPJ8HH-057	Lock Washer 8mm	8mm	4
58	JPJ8HH-058	Front Bearing Pillow Block		1
59	GB276	Ball Bearing	6004-2RS	1

Parts List for JPJ-8HH-M/JPJ-8HH-T Parallelogramm Jointer

Index No.	Part No.	Description	Size	Qty.
61	JPJ8HH-061	Driver Bit Torx T20		1
62	JPJ8HH-062	Spiral Cutterhead 8"		1
63	JPJ8HH-063	Key 6 x 6 x 35		1
64	10000101	Blade	15x15x2.5R100	40
65	JPJ8HH-065	L-Wrench Torx T20		1
66	JPJ8HH-066	Flat Head Torx T20	M6x 15	40
67	JPJ8HH-067	Inter Retaining Ring	47mm	1
68	GB276	Ball Bearing	6005-2RS	1
69	JPJ8HH-069	Rear Bearing Pillow Block		1
70	JPJ8HH-070	Cutterhead Pulley		1
71	JPJ8HH-071	Cutterhead Pulley Washer		1
72	GB70.1	Socket Head Cap Screw	M8x25	1
73	GB70.1	Socket Head Cap Screw	M8x80	1
74	JPJ8HH-074	Guard Clamp		1
75	JPJ8HH-075	Cutterhead Guard		1
77	JPJ8HH-077	Torsion Spring		1
78	JPJ8HH-078	Roll Pin	3x16 mm	1
79	JPJ8HH-079	Spring Retainer		1
80	JPJ8HH-080	Outfeed Table Lip		2
81	GB96	Flat Washer	6mm	6
82	GB70.1	Socket Head Cap Screw	M6 x20	6
83	JPJ8HH-083	Outfeed Table		1
84	JPJ8HH-084	Slotted Pin W/Hole		2
85	JPJ8HH-085	Bumper		2
86	GB93	Lock Washer	6mm	4
87	GB70.1	Socket Head Cap Screw	M6x25	4
88	JPJ8HH-088	Table Base		1
89	JPJ8HH-049	Rivet	2x4mm	2
90	JPJ8HH-090	Height Scale		1
91	JPJ8HH-091	Adjusting Screw		2
92	JPJ8HH-092	Hex Nut	M10	4
93	GB77	Socket Set Screw	M6x10	8
94	GB79	Socket Set Screw	M6x10	8
95	JPJ8HH-095	Adjusting Screw		1
96	JPJ8HH-096	Extension Spring		2
97	JPJ8HH-097	Slotted Pin W/Hole		2
98	JPJ8HH-098	Chip Breaker		1
99	JPJ8HH-099	Flat Washer	6mm	2
100	GB5781	Hex Cap Screw	M6x12	2
101	GB96	Flat Washer	8 mm	2
102	JPJ8HH-102	Adjustable Handle M8x30		2
103	JPJ8HH-103	Eccentric Bushing		8
104	JPJ8HH-104	Table Shaft 281mm		3
105	GB77	Socket Set Screw	M8x16	1
106	JPJ8HH-106	Table Shaft 281mm		1
107	JPJ8HH-107	Pointer		1
108	JPJ8HH-108	Roll Pin	3x10	1
109	GB819	Flat Head Cap Screw	M4x10	1
110	JPJ8HH-110	Pivot Bracket		4
111	JPJ8HH-111	Adjusting Block		4
112	GB41	Hex Nut	M12	2
113	JPJ8HH-113	Lever		2
114	JPJ8HH-114	Knob M12		2
115	GB70.1	Socket Head Cap Screw	M8x40	8

Parts List for JPJ-8HH-M/JPJ-8HH-T Parallelogram Jointer


Index No.	Part No.	Description	Size	Qty.
116	JPJ8HH-116	Clamp Plate		8
117	JPJ8HH-117	Medium Adjusting Screw		1
118	JPJ8HH-118	Push Block		2
119	JPJ8HH-119	Wrench 8 X 10mm Open-Ends		1
120	JPJ8HH-120	Wrench 12 X 14mm Open-Ends		1
121	JPJ8HH-121	Hex Wrench 2.5mm	2.5mm	1
122	JPJ8HH-122	Hex Wrench 4mm	4mm	1
123	JPJ8HH-123	Hex Wrench 5mm	5mm	1
124	JPJ8HH-124	Hex Wrench 6mm	6mm	1
125	JPJ8HH-125	Hex Wrench 8mm	8mm	1
129	JPJ8HH-129	Control Panel		1
130	JPJ8HH-130	Switch		1
131	JPJ8HH-131	Switch Box		1
132	JPJ8HH-132	Switch Plate		1
133	JPJ8HH-133	Tap Screw	M4x8	2
134	JPJ8HH-134	Control Pedestal		1
135	JPJ8HH-135	Flange Screw	M6x12	2
136	GB70.1	Socket Head Cap Screw	M10x25	2
137	GB93	Lock Washer	10mm	2
138	GB96	Flat Washer	10mm	1
142	JPJ8HH-142M	Power Cord		1
	JPJ8HH-142T	Five-Pin Plug P551 & Power Cord		1
143	JPJ8HH-0143	Motor Cord	400V	1
144	JPJ8HH-0144	Control Panel Cord		1
200	GB818	Pan Head Cap Screw	M5x16	6
201	GB96	Flat Washer	5mm	6
202	JPJ8HH-202	Rear Panel		1
203	GB5789	Flange Screw	M6x12	2
204	JPJ8HH-204	Belt Guard		1
205	JPJ8HH-205	Stand		1
206	GB96	Washer Washer	6 mm	2
207	GB41	Hex Nut	M6	2
208	GB818	Pan Head Cap Screw	M5x16	1
209	GB96	Flat Washer	5mm	4
210	JPJ8HH-210	Dust Chute		1
211	GB41	Hex Nut	M8	2
212	GB96	Flat Washer	8mm	4
213	JPJ8HH-213	Sleeve		2
214	JPJ8HH-214	Universal Wheel		2
215	GB5781	Hex Cap Screw	M8x65	2
216	JPJ8HH-216	Motor Bracket		2
217	JPJ8HH-217	Flange Nut 5/16-18		4
218	JPJ8HH-218	Carriage Bolt 5/16-18 X 3/4		4
219	JPJ8HH-219	Carriage Bolt 5/16-18 X 1-1/4		4
220	JPJ8HH-220	Flat Washer 5/16		4
221	JPJ8HH-221	Hex Nut 5/16-18		4
222	JPJ8HH-222	Adjustable Foot 3/8-16 X 1-3/4		2
223	JPJ8HH-223	Hex Nut 3/8-16		2
224	JPJ8HH-224	Poly V-Belt		1
225	JPJ8HH-225	Aluminium Motor Pulley		1

Parts List for JPJ-8HH-M/JPJ-8HH-T Parallelogram Jointer

Index No.	Part No.	Description	Size	Qty.
226	GB77	Socket Set Screw	M6x10	2
227	JPJ8HH-227	Key 5 x 5 x 30		1
228	JPJ8HH-228M	Motor ~ 230V 50hz 1ph	230V	1
	JPJ8HH-228T	Motor 3~400V 50hz 3ph	400V	1
229	GB5781	Hex Cap Screw	M8x25	8
230	GB93	Lock Washer	8mm	8
242	JPJ8HH-242	Ext Retaining Ring	9mm	2
243	GB96	Flat Washer	12mm	2
244	JPJ8HH-244	Captive Pin		1
245	GB5781	Hex Cap Screw	M8x50	1
246	GB96	Flat Washer	8mm	1
247	GB41	Hex Nut	M8	1
248	GB41	Hex Nut	M10	2
249	GB96	Flat Washer	10mm	2
250	GB5781	Hex Cap Screw	M8x100	1
251	GB96	Flat Washer	8mm	2
252	JPJ8HH-252	Trolley Wheel Axle		1
253	JPJ8HH-253	Inter Retaining Ring 35mm	35mm	4
254	GB276	Ball Bearing	6202-2RS	2
255	JPJ8HH-255	Trolley Wheel		1
256	JPJ8HH-256	Trolley Wheel Sleeve		1
257	JPJ8HH-257	Trolley Universal Kit		1
258	GB96	Flat Washer	10mm	1
259	GB6720	Lock Nut	M12	1
260	GB96	Flat Washer	M10x55	2
261	JPJ8HH-261	Pedal Bracket		1
262	JPJ8HH-262	Pedal		1
262A	JPJ8HH-262A	Pedal Assembly		1
	JPJ8HH-ID-M	JET ID Label (Not shown)	230V	1
	JPJ8HH-ID-T	JET ID Label (Not shown)	400V	1
	JPJ8HH -ML-M	Motor Label (Not shown)	230V	1
	JPJ8HH -ML-Y	Motor Label (Not shown)	400V	1
	JET-LOGO	JET -LOGO (Not shown)		1
	JPJ8HH-WR	Warning Label (Not shown)		1

Wiring Diagram for JPJ-8HH-M/JPJ-8HH-T Parallelogramm Jointer

JR037..... ~ 230V, 50Hz



Wiring Diagram for JPJ-8HH-M/JPJ-8HH-T Parallelogramm Jointer

JR038..... 3 ~ 400V, 50Hz

